

Meridian IVR

Maintenance and Diagnostics Guide

Publication number: 555-9001-500
Product release: 2.0/I
Document release: Standard 1.0
Date: February 1996

© Northern Telecom 1996
All rights reserved

Printed in the United States of America

Information is subject to change without notice. Northern Telecom reserves the right to make changes in design or components as progress in engineering and manufacturing may warrant.

Nortel, Meridian IVR, Meridian Mail, and ACCESS are trademarks of Northern Telecom. DEC and VT420 are registered trademarks of Digital Equipment Corporation. HP, LaserJet and ThinkJet are registered trademarks of Hewlett-Packard Company. X Window System and X are trademarks of the Massachusetts Institute of Technology. MVME is a registered trademark of Motorola Incorporated. NCD is a registered trademark of Network Computing Devices Inc. Motif is a registered trademark of Open Software Foundation Inc. SCO UNIX is a registered trademark of the Santa Cruz Operation, Inc. Voicetek and VTK are trademarks of Voicetek Corporation. Touch tone is a trademark of Bell Canada.

Publication history

February 1996

This document is the first standard issue for Meridian IVR Release 2.0/I.

Contents

About this guide xv

Who should use this guide	xv
How to use this guide	xv
Additional Meridian IVR guides	xvii
Third-party documentation	xvii
Conventions used in this guide	xviii

Chapter 1: Diagnostics overview 1-1

Components tested	1-1
Diagnostic routines	1-2
Power On Self Test (POST) diagnostics	1-2
DOS-based utilities	1-2
UNIX-based utilities	1-3

Chapter 2: Fault isolation 2-1

Gathering information	2-1
Examining interprocess communication queues	2-5
Meridian IVR log files	2-6
Examining the error logs	2-7
Examining the /tmp directory	2-7
Examining the Meridian IVR console window	2-7
Reading Transaction Log Report self-diagnostic messages	2-7
Meridian Access link setup problem	2-8
Troubleshooting operational problems	2-9
Failure to synchronize the Meridian Access link	2-9
An application cannot run	2-9
Meridian IVR cannot run	2-10
A call cannot reach Meridian IVR	2-10
Failure to access the voice prompt mailbox	2-11
Meridian Mail console window not available	2-11

Chapter 3: Troubleshooting procedures	3-1
Initial system start-up quick reference checklist	3-1
Specific operational problems and corrective actions	3-3
Power light does not work	3-3
System cooling fans do not rotate	3-4
No characters appear on screen	3-5
Characters are distorted or incorrect	3-6
Incorrect or no beep codes	3-6
Diskette drive activity light does not light	3-7
Hard disk drive activity light does not light	3-7
Testing hardware components	3-8
Intel ALTAIR motherboard	3-8
Intel Pentium P5-75 MHz or 100 MHz CPU	3-12
Onboard dynamic random access memory	3-13
Mouse and onboard mouse controller	3-14
Keyboard and onboard keyboard controller	3-15
Monitor and video adapter card	3-16
SCSI hard disk and controller	3-18
SCSI tape drive	3-19
Floppy disk drive and floppy disk controller	3-20
Testing expansion cards	3-21
IBM 3270 SNA card (Arnet SYNC/570)	3-21
Ethernet card (ZNYX PCI)	3-23
VT100 serial card (DigiBoard PC/Xe board)	3-26
Token ring card (Madge Smart 16/4 AT Plus)	3-30
Fax Card (Dialogic VXF/40E)	3-33

Chapter 4: Maintenance activities	4-1
Preparing for field maintenance	4-1
Application processor power-down	4-5
Accessing the server chassis	4-6
Removing and installing the diskette drive	4-13
Removing and installing a mass storage device	4-16
Add-in boards	4-21
System base board and I/O panel	4-26
Front panel board	4-30
Fans	4-32
Hard drive bay assembly	4-41
Swapping SCSI hard drives	4-46
System board SIMMs	4-47

Cache memory module	4-53
Video memory	4-54
Real-time clock chip.	4-56
Recovering and updating the BIOS	4-58

Chapter 5: Software reinstallation 5-1

Software information	5-2
Installing the operating system	5-2
Rebooting the system	5-7
Reinstalling the IVR application software.	5-8
Installing a second hard drive	5-11
Installing a second DigiBoard	5-13

Appendix A: POST diagnostics A-1

Hot keys	A-2
Security	A-2
System reset	A-3
POST error and signal codes.	A-4
POST beep codes	A-4
POST codes and countdown codes	A-5
Normal port-80 codes and countdown codes	A-7
POST error codes and messages	A-12

Appendix B: MTA diagnostics reference B-1

MTA Testview	B-1
Execution sequence	B-3
Looping options	B-4
Test window	B-4
Error messages	B-5
Runtime enviroment.	B-5
Sources of Run-time flags	B-8
PKG file	B-9
Subtest syntax	B-9
Cloning	B-10
Attribute flag	B-10
Product_code sections	B-10
Attributes	B-12
Invocation	B-12
Function keys.	B-13
Using menus	B-14
Test module menu	B-16

Subtest menu	B-18
Errors menu	B-20
Summary menu	B-20
Configuration menu	B-21
Options menu	B-24
Subtest order submenu	B-26
Invoking Testview	B-27
Using the T Command	B-29
Standard error codes	B-34

Appendix C: System configuration utility **C-1**

Configuring your system with SCU	C-1
SCU configurable features	C-5

Appendix D: UNIX diagnostics **D-1**

accdiag	D-1
backup_default.bup file	D-2
dappl	D-4
System Applications Monitor	D-8
devnt	D-12
dsysf	D-12
kccheck	D-15
readdongle	D-15
Transaction logs	D-16
Event log	D-16
Sec log	D-17
Start log	D-17
Xconsole log	D-18
rstat	D-19
sched	D-20
testivr.vpf	D-20
testfax.vpf	D-20
Vrs tools	D-21
dpsm	D-21
gmessage	D-21
maudit	D-21

Appendix E: X terminal support **E-1**

Cabling the X terminal	E-1
Configuring the X terminal	E-3

Appendix F: Cable pinouts **F-1**

DigiBoard connectors.	F-1
U.S. Robotics modem	F-2

Appendix G: Customizing the user interface **G-1**

Modifying resource files/colors.	G-1
The user interface language directory	G-2
Items in the UI_LANG directory.	G-4
Modifying the UIF.HLP file	G-8

Appendix H: Console redirection **H-1**

Appendix I: Error messages **I-1**

Messages 0 To 99: Call Logic Interpreter (CLI)	I-2
Messages 100 to 199: MRS Interface Process (VIP)	I-15
Messages 200 To 299: MRS Input And MRS Output Process (MRS)	I-24
Messages 300 To 399: Pool Manager (PMG)	I-26
Messages 400 To 499: MRS Resource Manager (VRM)	I-28
Messages 500 To 518: SQL Database Server (QDS)	I-38
Messages 600 To 699: System Administration Interface (SAI)	I-40
Messages 700 To 799: Statistics Process (UST)	I-42
Messages 800 To 899: Database Server (DBS)	I-44
Messages 900 To 999: Voice File Transfer Process (VFT)	I-47
Messages 1000 To 1099: User Function Process (USR)	I-52
Messages 1100 To 1199: Call Scheduler (CSC)	I-53
Messages 1200 To 1299: Prompt Loading Facility (PLF)	I-55
Messages 1300 To 1399: System Administration Process (SAD)	I-56
Messages 1400 To 1499: Graphical System Monitor (XAI)	I-59
Messages 1500 To 1599: System Application Monitor Process (SAM)	I-60
Messages 1600 To 1699: Alternate Error Handling Process (UEH)	I-61
Messages 1700 To 1799: Graphical Prompt Manager (XPM)	I-61
Messages 1800 - 1899: Terminal Resource Server (TRS)	I-62
Messages 1900 To 1999: Database Editor Command Line Messages (SDE)	I-80
Messages 2000 - 2099: CLI_S	I-82
Messages 2100 - 2199: TRSC	I-86

Messages 2200 To 2299: Generic SQL Data Server (GDS, IDS, ODS, FDS, SDS)	I-87
Messages 2300 - 2399: SASE	I-90
Messages 2400 - 2499: TRSL	I-91
Messages -1 - -82: License Manager	I-91

Glossary

Glossary-1

List of figures

Figure 3-1	Motherboard connections.....	3-9
Figure 4-1	ESD wrist strap	4-2
Figure 4-2	Testing ESD wrist strap.....	4-2
Figure 4-3	Using conductive foam pad.....	4-3
Figure 4-4	Required tools	4-4
Figure 4-5	Powering down the server.....	4-5
Figure 4-6	Peripheral cables	4-6
Figure 4-7	Side cover, back view	4-8
Figure 4-8	Side cover, tabs detail	4-10
Figure 4-9	Side cover, EMI gaskets detail	4-11
Figure 4-10	Disconnecting the diskette drive	4-14
Figure 4-11	Remove diskette carrier assembly	4-15
Figure 4-12	SCSI cable installation	4-17
Figure 4-13	Installing the mass storage device	4-19
Figure 4-14	Removing the metal shield	4-20
Figure 4-15	Removing the expansion slot cover	4-23
Figure 4-16	Add-in board installation.....	4-25
Figure 4-17	System base board and I/O panel components	4-27
Figure 4-18	Removing front panel board	4-31
Figure 4-19	Removing Fan 1	4-33
Figure 4-20	Removing metal panel from Fan 1	4-34
Figure 4-21	Fan 1 replacement	4-36
Figure 4-22	Removing Fan 2	4-38
Figure 4-23	Mounting Fan 2 assembly	4-39
Figure 4-24	Mounting Fan 2 to chassis	4-40
Figure 4-25	Opening metal front door	4-42
Figure 4-26	Removing front metal door	4-43
Figure 4-27	SIMM banks	4-48
Figure 4-28	Installing system board SIMMs	4-50
Figure 4-29	Positioning SIMMs	4-52

Figure 4-30	Replacing the video DRAM chip	4-55
Figure 4-31	Replacing real-time clock chip	4-58
Figure 4-32	System board jumper settings.....	4-60
Figure 5-1	Main menu	5-14
Figure 5-2	Config menu.....	5-15
Figure 5-3	Pick List menu.....	5-16
Figure 5-4	Board Configuration screen (filled in for second Digi-Board)	5-17
Figure 5-5	DigiScreen screen.....	5-18
Figure D-1	dappl command application listing output	D-5
Figure D-2	dappl command graphical structure chart output ...	D-7

List of tables

Table 2-1	Meridian IVR processes	2-2
Table 3-1	System start-up reference chart.....	3-1
Table 3-2	Power light troubleshooting.....	3-3
Table 3-3	Motherboard connections.....	3-10
Table 3-4	SYNC/570 Interrupt/Memory address and I/O port addresses.....	3-21
Table 3-5	SYNC/570 dip switch settings	3-22
Table 3-6	Diag312 error messages	3-25
Table 3-7	VT100 Interrupt/memory and I/O port addresses..	3-26
Table 3-8	Token ring interrupt/memory and I/O port addresses	3-31
Table 3-9	Token ring diagnostic error messages	3-32
Table 4-1	Base board components	4-28
Table 5-1	Dip switch settings for second DigiBoard.....	5-13
Table A-1	POST and related processes	A-1
Table A-3	Security events.....	A-2
Table A-2	POST hot key combinations.....	A-2
Table A-4	Reset activators	A-3
Table A-5	POST Beep Code descriptions	A-4
Table A-6	Recovery port-80 codes and countdown codes	A-6
Table A-7	Normal port-80 codes and countdown codes.....	A-7
Table A-8	Onscreen POST codes and messages	A-12
Table B-1	Testview menus	B-2
Table B-2	Test module options.....	B-3
Table B-3	Run-list functions.....	B-4
Table B-4	Run-time flags in Testview	B-6
Table B-5	Required run-time flags	B-6
Table B-6	Run-time control flags	B-7

Table B-7	Attribute flags	B-10
Table B-8	Single-character attributes	B-12
Table B-9	Function keys	B-13
Table B-10	Testview selection keys	B-14
Table B-11	Text positioning keys.....	B-15
Table B-12	Data selection keys	B-16
Table B-13	Test module keys	B-16
Table B-14	Subtest menu keys.....	B-18
Table B-15	Errors menu options.....	B-20
Table B-16	Summary menu options	B-21
Table B-17	Change menu colors options	B-24
Table B-18	Run-time edit flags	B-25
Table B-19	Testview flags	B-28
Table B-20	T commands	B-30
Table B-21	Flags parameter groups	B-31
Table B-22	Flag description.....	B-32
Table B-23	T error codes.....	B-34
Table C-1	SCSI device settings	C-4
Table C-2	SCU configurable features	C-5
Table D-1	System Status window function keys	D-1
Table D-2	System Operational Measurements function key options.....	D-2
Table D-3	Flags for dappl command.....	D-4
Table D-4	sam data capture list.....	D-8
Table D-5	sam command line variables.....	D-9
Table D-6	sam sample output.....	D-10
Table D-7	sam command flags	D-11
Table F-1	DB-25 connector pin assignments	F-1
Table G-1:	VOICE_LANG	G-3
Table I-1	Modem settings for console redirection	H-2

List of procedures

Procedure 2-1	Checking Meridian Access link settings.....	2-8
Procedure 2-2	Checking system configuration parameters.....	2-10
Procedure 3-1	Add-in video board troubleshooting	3-5
Procedure 3-2	Verifying connections.....	3-8
Procedure 3-3	Performing motherboard diagnostic routine	3-11
Procedure 3-4	CPU diagnostics	3-13
Procedure 3-5	DRAM diagnostics	3-14
Procedure 3-6	Mouse diagnostics	3-15
Procedure 3-7	Keyboard diagnostics.....	3-16

Procedure 3-8	Monitor and adapter diagnostic.....	3-17
Procedure 3-9	Running SCSI hard disk and controller diagnostics.....	3-18
Procedure 3-10	Running SCSI tape drive diagnostics	3-19
Procedure 3-11	Running floppy disk drive diagnostics.....	3-20
Procedure 3-12	Testing the Arnet SYNC/570 card.....	3-22
Procedure 3-13	Using the ping utility.....	3-23
Procedure 3-14	Running the diag312 diagnostic.....	3-24
Procedure 3-15	Running the UD-CISC diagnostic	3-27
Procedure 3-16	Running the MPI diagnostic	3-27
Procedure 3-17	Running the loop back test	3-28
Procedure 3-18	Using the express_adm command	3-30
Procedure 3-19	Configuring the Madge Smart 16/4 AT Plus Ring- node.....	3-31
Procedure 3-20	Token ring card diagnostics	3-32
Procedure 3-21	Using the faxdiag utility.....	3-33
Procedure 4-1	Powering down the application processor	4-5
Procedure 4-2	Removing the side cover	4-7
Procedure 4-3	Replacing the side cover.....	4-11
Procedure 4-4	Removing the front panel and door assembly ..	4-12
Procedure 4-5	Replacing the front panel and door assembly...	4-12
Procedure 4-6	Removing the diskette drive.....	4-13
Procedure 4-7	Installing a diskette drive.....	4-15
Procedure 4-8	SCSI cable installation	4-16
Procedure 4-9	Installing a mass storage device.....	4-19
Procedure 4-10	Mass storage device removal	4-21
Procedure 4-11	Add-in board installation	4-22
Procedure 4-12	Add-in board removal.....	4-26
Procedure 4-13	System base board and I/O panel removal.....	4-29
Procedure 4-14	System base board and I/O panel installation ..	4-29
Procedure 4-15	Front panel board removal.....	4-30
Procedure 4-16	Front panel board replacement.....	4-32
Procedure 4-17	Fan 1 removal	4-33
Procedure 4-18	Fan 1 replacement.....	4-35
Procedure 4-19	Fan 2 removal	4-37
Procedure 4-20	Fan 2 replacement.....	4-39
Procedure 4-21	Hard drive bay assembly removal.....	4-41
Procedure 4-22	Removing the SCSI backplane	4-44
Procedure 4-23	Replacing the SCSI backplane	4-45
Procedure 4-24	Replacing the hard drive bay assembly	4-45
Procedure 4-25	Mounting a SCSI hard disk drive in a plastic	

	carrier	4-46
Procedure 4-26	Installing a SCSI drive in a hard drive bay	4-47
Procedure 4-27	Installing system board SIMMs	4-50
Procedure 4-28	Removing system board SIMMs	4-53
Procedure 4-29	Installing a cache memory module	4-53
Procedure 4-30	Removing a cache memory module	4-54
Procedure 4-31	Installing the video DRAM chip	4-55
Procedure 4-32	Removing the video DRAM chip	4-56
Procedure 4-33	Removing the real-time clock chip	4-57
Procedure 4-34	Installing the real-time clock chip	4-58
Procedure 4-35	Removing or installing a jumper.....	4-61
Procedure 4-36	Recovering the BIOS	4-61
Procedure 4-37	Updating the BIOS	4-62
Procedure 5-1	Rebooting the system using diskettes	5-3
Procedure 5-2	Reinstalling the operating system using the SCO Operating System tape	5-4
Procedure 5-3	Rebooting the system	5-8
Procedure 5-4	Reinstalling the IVR software	5-9
Procedure 5-5	Installing a second hard drive	5-11
Procedure 5-6	Configuring a second DigiBoard	5-13
Procedure C-1	Running SCU	C-1
Procedure C-2	Running the SCSI select utility.....	C-4
Procedure D-1	Accessing the event log	D-15
Procedure D-2	Accessing the sec log	D-16
Procedure D-3	Accessing the start log.....	D-17
Procedure D-4	Accessing the xconsole log.....	D-17
Procedure E-1	Connecting the X terminal to the application processor	E-2
Procedure E-2	Setting up the X terminal in the network	E-3
Procedure E-3	Rebooting the X terminal	E-4
Procedure E-4	Responding to the default hosts login chooser window	E-5
Procedure H-1	Setting up your system for remote support.....	H-1